

## Care and Maintenance

---

- Clean your PCR using a mild soap and lukewarm water. Never bleach or attempt to dye the belts because this could seriously affect their strength.
- Keep the belts free of polish, oils, chemicals, and particularly battery acid.
- Never attempt to make modifications or changes that will prevent the PCR from operating properly.
- Keep sharp-edged or damaging objects away from belts and other parts of the child restraint system.

**HSM**  
Transportation

8936 Northpointe Executive Park Dr Ste 200  
Huntersville, NC 28078  
Tel: 800-437-4220  
[www.hsmstransportation.com](http://www.hsmstransportation.com)



**HSM**  
Transportation

**Instruction Manual**



**C.E. White**  
**Portable Child Restraint (PCR)**



## PCR INSTALLATION



**1** Place PCR on seat as shown.



**2** Unfold PCR and place on seat as shown.



**7** Pull belt located at front of PCR cushion around front of school bus seat cushion and let belt hang.



**8** Hook belt from step 4 to snap clip on belt from step 7. Adjust to create a snug fit.



**3** Drape PCR top belt over school bus seat back and let belt hang down.



**4** Locate belt that comes out of bottom of PCR cushion.



**9** Hook top belt from step 3 to snap clip on bottom belt from step 6 together as shown. Adjust to create a snug fit.



**10** Unfasten seat buckles before placing child in PCR as shown.



**5** Push belt from step 4 through bight of school bus seat. Make sure belt is flat and not twisted.



**6** Pull belt and PCR to back of school bus seat. Belt should look as shown when finished.

# HSM

Transportation

8936 Northpointe Executive Park Dr Ste 200  
Huntersville, NC 28078  
Tel: 800-437-4220  
www.hsmtransportation.com

This add on child seat is designed for use only on school bus seats by children who weigh between 20 and 90 pounds.