

Care and Maintenance

- Clean your PCR using a mild soap and lukewarm water. Never bleach or attempt to dye the belts because this could seriously affect their strength.
- Keep the belts free of polish, oils, chemicals, and particularly battery acid. Never attempt to make modifications or changes that will prevent the PCR from operating properly.
- Keep sharp-edged or damaging objects away from belts and other parts of the child restraint system.

HSM
Transportation

8936 Northpointe Executive Park Dr Ste 200
Huntersville, NC 28078
Tel: 800-437-4220

www.hsmtransportation.com



Instruction Manual



**C.E. White
Portable Child Restraint (PCR)**



PCR INSTALLATION



1 Place PCR on seat as shown.



2 Unfold PCR and place on seat as shown.



7 Pull belt located at front of PCR cushion around front of school bus seat cushion and let belt hang.



8 Hook belt from step 4 to snap clip on belt from step 7. Adjust to create a snug fit.



3 Drape PCR top belt over school bus seat back and let belt hang down.



4 Locate belt that comes out of bottom of PCR cushion.



9 Hook topbelt from step 3 to snap clip on bottom belt from step 6 together as shown. Adjust to create a snug fit.



10 Unfasten seatbuckles before placing child in PCR as shown.



5 Push belt from step 4 through bight of school bus seat. Make sure belt is flat and not twisted.



6 Pull belt and PCR to back of school bus seat. Belt should look as shown when finished.

HSM
Transportation

8936 Northpointe Executive Park Dr Ste 200
Huntersville, NC 28078
Tel: 800-437-4220
www.hsmstransportation.com

This add on child seat is designed for use only on school bus seats by children who weigh between 20 and 90 pounds.